

# B-TREK

BY SENTEY

## S8

LS-4460

### Bluetooth Stereo Speaker



USER MANUAL

## User Manual


Thank you for your purchase of the B-Trek S8 Bluetooth Speaker.

**Please read the manual carefully before using your speaker as it will provide you with information to operate and maintain your speaker correctly.**

### PRODUCT SPECIFICATIONS

Microphone Directivity	Omnidirectional	
Speakers	Speaker	Stereo
	Drive Diameter	ø46 mm
	Impedance	4Ω
	Frequency Response	80Hz~20KHz
	Output Power	5W x 2
	Signal to Noise Ratio	≥75dB
	T.H.D	<1%
	Sensitivity (S.P.L)	90±3dB
Battery Life	Up to 7 hours (via Bluetooth)	
	Up to 8 hours (via AUX Line in input)	
Battery Capacity	3200mAh	
Inputs	3.5mm Aux line in	
Coating	Soft Matte	
Dimensions	18.7 x 5.9 x 7.4 cm (W x D x H)	
Net Weight	550 g (Speaker)	
Warranty	1 Year	
Bluetooth Version	V4.0	
Bluetooth Range	33FT (10 m)	
Bluetooth Profiles	DSP, A2DP, AVRCP, HSP, Hands-free Profile	

## BUTTON FUNCTIONALITY & DIAGRAM



### References:

- |                            |                                  |
|----------------------------|----------------------------------|
| 1. Microphone              | 6. Volume down                   |
| 2. Previous track          | 7. Volume up                     |
| 3. Pairing button          | 8. On/Off Switch                 |
| 4. Next track              | 9. AUX line in                   |
| 5. Play/Pause/Answer phone | 10. Charging port (5V/Micro USB) |

## FEATURES

Elegant design with soft rubberized finish

Bluetooth technology with 10m (30ft) range

Hands free function on Bluetooth mode and compatible phone.

AUX line in to allow direct connection to any device through a 3.5mm audio cable

Deluxe carry bag for easy transportation without damaging or dirtying your speaker

Rechargeable battery that charges through micro USB cable

## OPERATIONAL INSTRUCTIONS

### 1. Basic Operation

- Move the On/Off switch to the on position to power on the speaker.
- Press the play/pause/answer button (▶) to pause or play a song, or pick up a phone call when in Bluetooth hands free mode.
- Press the previous track or next track button (◀, ▶) to change to the previous or next song.
- Press the volume down or volume up button (–, +) to adjust the volume accordingly.

### 2. Bluetooth Operation

- Pairing: When the speaker is turned on, it will automatically be in pairing mode if not already paired to a device. Search for B-Trek S8 in your device's pairing screen and select to connect it. If asked for a pairing code or password enter 0000 (four zeroes). If not in pairing mode for some reason, turn the device off and on again while making sure no other devices are paired to the speaker until you can see the speaker for pairing in your device or press and hold the pairing button until the speaker beeps indicating it is in pairing mode.
- Music playback & Volume can be controlled from the device or the speaker by using the Basic Operation instructions above.
- Hands Free: If the speaker is paired with a mobile phone, it can function as a

hands free device. When you have an incoming call press the play/pause/answer button (▶) to answer. Hold the play/pause/answer button (▶) for 3 second to reject the call.

### 3. AUX line in Operation

- Inserting a 3.5mm auxiliary audio cable into the AUX line in port will automatically set the speaker in the AUX line in mode. You must disconnect the 3.5mm auxiliary audio cable to go back into Bluetooth mode.
- The volume can be controlled as indicated in the Basic Operation above.
- Music playback can be controlled from the device or the speaker (if the connected device supports commands through 3.5mm audio cable) by using the Basic Operation instructions above.

### 4. Charging Operation

- Connect the speaker to a laptop, computer, power bank, or power adapter with the Micro USB cable included (5V/500mA) through the charging port. The LED indicator will turn solid red while charging and will turn off when fully charged.
- Please charge the battery fully before the first use of the speaker.

## ADDITIONAL INFORMATION

Hands free functionality is only available in the Bluetooth mode and on mobile phone that support the hands free Bluetooth profile.

Do not use the speaker in water

Avoid using the speaker in extremely humid environments

Avoid placing the speaker near strong magnets or strong magnetic fields.

LED indicators are as follows:

*Flashing blue: Bluetooth pairing mode*

*Solid blue: Bluetooth mode (connected)*

*Flashing red: Low battery*

*Solid red: Charging (in any mode)*

# B-TREK

BY SENTEY

**EN** DOWNLOAD ENGLISH PDF MANUAL AT:  
<http://www.sentey.com/en/support>

**ES** DESCARGA DE MANUAL EN FORMATO PDF EN ESPAÑOL:  
<http://www.sentey.com/es/support>

**PT** DOWNLOAD DO MANUAL PORTUGUÊS EM FORMATO PDF:  
<http://www.sentey.com/br/support>



Toll Free Number: USA 1-855-7SENTEY (1-855-773-6839)  
For more Information: [www.sentey.com](http://www.sentey.com) - [info@sentey.com](mailto:info@sentey.com)